



- J 1 : Radio port (Transceiver & Power supply) J 2 : GPS input & Serial port
- J 3 : Power supply (7 = +12v / 6 = GND) J 4 : LED control
- J 5 : PROFILE select (APRS Tracker is Non-installing. use for TinyTrak3plus ROM) (same is a J1-port 4pin)
- J 6 : ??? SW 5 : Pushing SW5 does the same operation as the use of the "PTT-IN"(J1 4pin) function.
- J 7 : Serial (J2) port +v select (Non-installing)
- J 8 : Mobile Type Rig or Handy Type Rig . R8 select jumper
- J 9 : use PTTIN mode. PTT signal D6 output switch. (Short is TinyTrak3 Compatible / Open is AT use)
- R 6 : AF Output Level Volume R 9 : AF Input Level Volume

< J 1 - Radio port >

- 1pin = Audio Out (to Rig MIC IN)
- 2pin = CARRIER DET (to Rig SQL pin) (**APRS Tracker not use**)
- 3pin = PTT OUT (to Rig PTT Signal)
- 4pin = SW1 (**APRS Tracker not use**)
- 5pin = Audio In (to Rig SP OUT)
- 6pin = GROUND
- 7pin = Power supply (+8v - +12v input)
- 8pin = PTT IN (The comparable result is obtained by pushing SW5, and it is also possible to use this pin.)
- 9pin = **Attention!! not - use!! not - connect!!**

< J 2 - GPS input & Serial port > (1pin,6pin,7pin,8pin,9pin is not use.)

- 2pin = Serial In
- 3pin = Serial Out
- 4pin = Serial V+ (Power +5v Output)
- 5pin = GROUND